




WELDPLAST S6



Leister Process Technologies
Galileo-Strasse 10
CH-6056 Kaegiswil/Switzerland

Tel. +41 41 662 74 74

Fax +41 41 662 74 16

www.leister.com

sales@leister.com

Operating instructions

(Translation of the original operating instructions)



Please read operating instructions carefully before use and keep for further reference.

Leister WELDPLAST S6 Hand extruder

Application

Hand extruder for welding thermoplastics from PE and PP filler rod with a diameter of 4 and 5 mm (other materials on enquiry) in the construction of containers, apparatus, pipelines and storage sites.

Electroconductive material (e.g. PE-EL) may not be welded.



Warning



Danger to life! Danger to life when opening up the tool, as live components and connections are exposed. Before opening the tool, unplug from the mains supply. Electrically conducting material (e.g. PE-EL) must not be welded.



Fire and explosion hazard with incorrect use of the hand extruder (e.g. overheating of the material), especially near combustible materials and explosive gases.



Danger of getting burned! Do not touch exposed metal parts and escaping plastized material. Do not point the hot air flow and escaping plastized material in the direction of people or animals.



Connect the tool to a **mains socket with protective earth**. Every interruption of the protective earth inside or outside of the tool is dangerous!

Only use extension cables with protective earth conductor.
Cross-section of conductor min. 3 x 4 mm²



Use ear protection.



Caution



The **voltage rating** stated on the name plate of the tool must correspond to the mains voltage.

In case of a power outage, the main switch and the drive must be switched off (loosen lock).



For personal protection on building sites we **strongly recommend** the tool to be connected to a RCCB (Residual Current Circuit Breaker).



The tool must be operated **under supervision**.

Heat can ignite flammable materials which are not in view.

The machine may only be used by **qualified specialists** or under their supervision. Children are not authorized to use this machine.




Protect tool from dampness and wet.

Conformity

Leister Process Technologies, Galileo-Strasse 10, CH-6056 Kaegiswi/Switzerland confirms that this product, in the version as brought into circulation through us, fulfils the requirements of the following EC directives. Directives: 2004/108, 2006/95

Harmonized Standards: EN 55014-1, EN 55014-2, EN 61000-6-2, EN 61000-3-11,
EN 61000-3-12, EN 50366, EN 62233, EN 60335-2-45

Kaegiswil, 15.05.2009


Bruno von Wyl
Technical Director




Christiane Leister
Owner

Disposal




Power tools, accessories and packaging should be sorted for environmental-friendly recycling. **Only for EC countries:** Do not dispose of power tools into household waste! According to the European Directive 2002/96/EC on waste electrical and electronic equipment and its incorporation into national law, power tools that are no longer suitable for use must be separately collected and sent for recovery in an environmental-friendly manner.

Technical data

Voltage	V~	230
Power consumption	W	4600
Frequency	Hz	50/60
Air flow (20 °C)	l/min	420
Air temperature	°C	max. 350
Plastifizer temperature	°C	max. 260
Emission level	L _{PA} (dB)	88
Sound power level	L _{WA} (dB)	96
Welding output	Ø 4 kg/h	PE 3.9 – 4.8 PP 3.4 – 4.0 (Average values at 50 Hz)
Welding output	Ø 5 kg/h	PE 4.9 – 6.0 PP 4.6 – 5.5 (Average values at 50 Hz)
Welding rod	mm	Ø 4 / Ø 5
Size L x B x H	mm	821 x 116 x 240 (without welding shoe)
Weight	kg	14 (without cable to mains)
Marking of conformity		CE
Approval mark		
Certification scheme		CCA
Protection class I		


Description of tool



- 1 Main switch
- 2 On/off switch drive
- 3 Potentiometer
- 4 Drive locking device
- 5 Display
- 6 Handle
- 7 Jacket heating
- 8 Welding shoe

- 9 Pre-heating nozzle
- 10 Tube clamp
- 11 Protective tube
- 12 Welding rod opening
- 13 Tool handle
- 14 Mains cable
- 15 Guiding grip
- 16 Hot air blower

32 Operating unit



- 17 Welding program
- 18 Actual value plast
- 19 Set value plast
- 20 Actual value air
- 21 Set value air
- 22 Bar display for drive
- 23 Welding output display
- 24 Menu key
- 25 Back key
- 26 Enter key
- 27 Down key
- 28 Select key
- 29 Up key
- 30 Status display for drive
- 31 Cursor

Working environment / safety




The hand extruder must not be used in inflammable environments or where explosion hazards exist. Ensure stable positioning during operation. The connection cable and the welding rod must remain unimpeded and must not hinder the user or others during operation.



Rest the hand extruder on a fireproof surface! Hot metal parts and the hot-air jet must have sufficient clearance from the surface and walls.

Handle Adjustment

1. Loosen the clamping by turning the **handle (6)** in counterclockwise direction.
2. Adjust **handle (6)** to the requested working position.
3. Tighten handle clamping again by turning **handle (6)** in clockwise direction.




Workplace

When not welding, the drive should be switched off with the **drive on/off switch (2)**.



Place the hand extruder on a stable, fire resistant base, as shown in the illustration.



Power supply



If an extension cable is used, it should have a cross section of at least $3 \times 4\text{mm}^2$ and must be permitted for the place where it is being used (e.g. outside) and labelled accordingly.




When using a power set for power supply, the nominal power rating for the power set is: $2 \times$ the nominal power rating of the hand extruder.



Starting procedure

Temperature monitoring prevents the hand extruder starting up in a cold state.



After switching on with the **main switch (1)**, press any key on the **operating unit (32)**. The device then heats up to the last ideal temperature set. When the ideal temperature is reached, a counter on the status display counts back from 310 seconds to zero. After this start-up process is complete, the device is ready to weld (status Ready*). The hand extruder takes around 8 minutes to reach its temperature range. If the power is only turned off for a short time, the start-up process does not need to be repeated.


Software and menu guide

The Weldplast manual welding extruder is fitted with convenient software, which makes working with the extruder easy for the user.

Key functions


Tap lightly on the keys to operate them.

• Operating window



Operating window functions	
	Menu selection
	Set contrast
	Heating on/off
	Change cursor position
	Selected parameter [+]
	Selected parameter [-]

• Menu selection



Menu selection functions	
	Menu selection / return to operating window
	Back to multifunctional display (Changed entry is not stored!)
	Select and return to operating window
	Select
	Cursor up / selected parameter +
	Cursor down / selected parameter -

Preparation for welding


Start window

After turning on the hand extruder with the **main switch (1)**, the device name and the current software version are shown in the **display (5)**. The start window is shown until any key is pressed on the **operating unit (32)**.



Operating window


The operating window shows the parameters currently set.



Setting parameters in the operating window

The **cursor (31)** shows which parameters can be set. After switching on, the cursor is on the «**SPEED**» position.


In the operating window, the following parameters can be selected with the **Select key (28)** and changed in their values with the **Up key (29)** and **Down key (27)**.



Adjusting the Output Capacity

Due to the seam form, the output capacity and the pre-heating period can be matched to each other.

- Pre-adjustment at the display
 - By pressing the **select key (28)**, set the cursor to the «**SPEED**» position.
 - Specify the maximum output value (60 to 100) via the **up key (29)** or **down key (27)** (indication via the **bar display for drive (22)**).
- Fine-adjustment during the welding procedure
 - By turning the **potentiometer (3)**, the output capacity of the maximal set output value (e.g. 85) can be reduced to the minimum.





The output capacity depends on the thickness of the welding wire. If the welding output is too high with the output display «60» and the potentiometer is set to «minimum», the next smallest welding rod thickness must be selected.

Setting the PLAST and AIR temperatures

- Set the cursor to the «PLAST» or «AIR» position by pressing the **Select key (28)**.
- Set the temperature value with the **Up (29)** or **Down (27)** keys.

Monitoring the welding parameters

The actual and ideal values of the AIR and PLAST temperatures are constantly monitored. If an actual value deviates from the relevant ideal value (value is outside the range of tolerance), this will be indicated by a change in status on the status **display of the drive (30)**. If necessary, the drive motor will be temporarily disabled. When the actual and ideal values of the AIR and PLAST temperatures are within the range of tolerance again, the message «Press any key» will appear on the status **display of the drive (30)**. Any key on the **operating unit (32)** must be pressed to release the drive motor again (preventing the device from being started up accidentally). The possible status display and the ranges of tolerance are shown in the following graphic and table.



No.	Status display	Status properties
1	Ready*	Ready to weld
2	M enabled	Deviation of the welding parameters > 10°C
3	Heat	Deviation of the welding parameters > -30°C, drive motor disabled
4	310s	Warm-up lock time of 310 sec., drive motor disabled
5	Too hot	Deviation of the welding parameters > +30°C, drive motor disabled
6	Press any key	Ready to weld, but drive motor is only released after pressing any key on the operating unit (32) .



Starting the welding process



- Fit the appropriate **welding shoe (8)** as required.
- Set the **potentiometer (3)** to max.
- Once the operating temperature is reached («READY*» status), welding can begin.
- Actuate the **drive on/off switch (2)**.
- Insert a 3 or 4 mm welding rod into the **welding-rod intake (12)**.
- The welding rod is automatically drawn in through the **welding-rod intake (12)**. The welding rod feed must take place without resistance.



CAUTION!

Never insert welding rods into both welding-rod intakes at the same time. Always operate the device with welding rod.

- Interrupt drive by releasing the **drive on/off switch (2)**.
- Direct the **pre-heating nozzle (9)** towards the welding zone.
- Pre-heat the welding zone with a fanning motion.
- Apply the device to the prepared welding location and actuate the **drive on/off switch (2)** again.
- Perform test welding by following the welding instructions from the material manufacturers and national standards or directives.
- Inspect test welding.
- Adjust the temperature setting and welding output as required.
- For long welding jobs, the **drive on/off switch (2)** can be locked-on with the **drive locking device (4)**.

Switching off the tool

- Disengage the **drive locking device (4)** and release the **drive on/off switch (2)**. Remove the welding material in the welding shoe so that the welding shoe will not be damaged when starting the next welding run.
- Switch off the heating systems with the **Enter key (26)**.
- Allow the device to cool down for approx 5 minutes.
- Switch off the **main switch (1)**.



Further settings

Contrast setting



Given unfavourable lighting conditions and fluctuations in the ambient temperature, the contrast on the display can be set in the operating window with the **back key (25)**.

Heating on/off



In the case of long interruptions (standby), the heating for PLAST and AIR can be deactivated with the **Enter key (26)** in the operating window.

Activate key lock

1. Menu



2. Key lock



3. Activate



If the key lock has been activated, key lock appears in the display.

The lock can be reset as follows:

Deactivate key lock

1. Back




2. Reset



3. Select



Confirmation with the Select key must immediately follow the reset!



Menüführung

Menu

Menu



Scroll



Select



Functions


Scroll



Select and
return



Return to
operating
window
Scroll



Welding parameters – Programming

Menu




Select program



Scroll



Enter



The hand extruder is suitable for the following types of thermoplastic:

- PP/PE-HD/PE-LD

Programs 1-3 are provided with preset values which can be adjusted during the welding process. The adjustments are not saved.

The free settings 1 - 4 are factory set and can be freely programmed. The parameters remain saved after the tool is switched off.

Welding program	Ideal PLAST [°C]	Ideal AIR [°C]
Free set 1 – 4	230	260
Prg1 PE-LD	220	260
Prg2 PE-HD	230	260
Prg3 PP	240	260


The **welding program (17)** currently set is shown in the operating display.

Setting the welding output

- Place the cursor on the «SPEED» position by pressing the **Select key (28)**.
- Set the welding output value (60 to 100) with the **Up key (29)** or **Down key (27)**.

Setting the PLAST and AIR temperature

- Place the cursor on the «PLAST» or «AIR» position by pressing the **Select key (28)**.
- Set temperature value with the **Up key (29)** or **Down key (27)**.



Replacing the welding shoe

- The welding shoe must only be replaced when the tool has attained its operating temperature.





**Work with temperature resistant gloves only.
Danger of getting burned!**

• Dismounting



Turn off the device while warm and disconnect from the power supply.

- Remove the welding shoe (8) with the **welding shoe holder (34)** by unfastening the **clamp screws (35)** from the **extruder nozzle (36)**.
- Every time the welding shoe is changed, clean the **extruder nozzle (36)** of welding residue and make sure that it is screwed in tightly.
- Remove welding shoe from the **welding shoe holder (34)** by unfastening the **fastening screws (33)**.
- **Assembly**
 - Fasten a **welding shoe (8)**, appropriate to the welding seam, onto the **welding shoe holder (34)** with **fastening screws (33)**.
 - The **welding shoe (8)** and **welding shoe holder (34)** must be tightened properly with the **fastening screws (35)**.



8 Welding shoe
35 Clamp screws
33 Fastening screws

34 Welding shoe holder
36 Extruder nozzle

Error messages

An error occurring is shown in the status display (30) (e.g. **Err04** Motor is overheated).

Display **ErrXX**

When an error occurs, the heating units for AIR and PLAST, as well as the drive motor, are switched off immediately!



Should this not take place, the tool must be disconnected from the mains supply immediately!

Further procedure with status display (30) **ErrXX**

- Note down the error code
- Disengage the **drive locking device (4)** and release the **drive on/off switch (2)**.
- Switch off the **main switch (1)**.



Start using the tool again under supervision and ensure that the extruder is not overheated from the outside.

- Eject the remaining plastic from the screw if possible.
- Should the error reoccur, the tool should be sent to the Service Centre to be checked, specifying the error code.

The following errors are recognised by the tool:

Display	Type of fault
Err01	Overheating of the air or defective temperature probe
Err02	Overheating of the plastic welding material or defective temperature probe
Err04	Overheating of the motor winding, motor is overheated
Err08	Overheating of the heating element, AIR or failure of the blower motor
Err10	Overheating of the electronics
Err40	Short circuit of the PLAST temperature probe

Several errors can occur at once e.g. **Err02** and **Err04** Display: **Err06** !

Further combinations are displayed with the letters A, B, C, D, E and F.

e.g. **Err08** and **Err02** Display **Err0A** !

Drive overheating protection

If the drive is overheated by external influences or because the PLAST temperature is too low, the internal temperature protection of the drive switches off (see **Err04**).



Accidental start-up protection for the drive

The drive motor is protected against accidental start-up after errors, e.g. overheating **Err04**. The message «Press any key» appears in the **status display of the drive (30)** while the drive motor is disabled. After the error has been corrected, press any key on the **operating unit (32)**. The message «Press any key» disappears from the status display.



Welding may continue.

Only **Leister accessories** may be used.




Transportable welding rod dereel holder


- The holder is designed for two welding rod reels with \varnothing 300 mm
- To ensure optimal rod dispensing, the welding rod should be passed through the **eyelets (41)** provided.

Welding-shoe assortment WELDPLAST S6 standard


Leister Process Technologies offers welding shoes for all the common seam geometries in various sizes:




Blank



V weld



Fillet weld



Overlap weld

Maintenance




Check the **power supply cord (14)** and plug for electrical and mechanical damage.



Clean the **extruder nozzle (32)** each time the welding shoe is replaced and remove any welding deposits.

Service and repair

- Repairs should only be carried out by authorized **Leister Service Centres**. They guarantee a specialised and reliable **Repair Service within 24 hours** using original spare parts in accordance with the circuit diagram and spare parts list.
- If the service message appears with the **Service Code 1** after switching on WELDPLAST S6, the state of the carbon brushes should be checked by an authorised **Leister Service Centre** and the carbon brushes replaced, if necessary.
- The display can be removed with the  **Select key (28)**.
- The hand extruder can be used again for a short time.
- If the carbon brushes are not replaced within a short time, the drive will run until the mechanical brush reaches its limit stop. No more error messages appear on the display, the drive no longer runs.

Service

Code 1

Check drive
brushes



Warranty


- For this tool, we generally provide a warranty of one (1) year from the date of purchase (verified by invoice or delivery document). Damage that has occurred will be corrected by replacement or repair. Heating elements are excluded from this warranty.
- Additional claims shall be excluded, subject to statutory regulations.
- Damage caused by normal wear, overloading or improper handling is excluded from the guarantee.
- Guarantee claims will be rejected for tools that have been altered or changed by the purchaser.

Technical data and specifications are subject to change without prior notice





Your authorised Service Centre is:



Leister Process Technologies
Galileo-Strasse 10
CH-6056 Kaegiswil/Switzerland

Tel. +41 41 662 74 74

Fax +41 41 662 74 16

www.leister.com

sales@leister.com